



Instruction Manual



PARTS LIST

A x 2




B x 8




C x 2



D x 2




E x 4




F x 4




G x 4



H x 5




I x 2




J x 8




K (M6x30) x 16




L (M6x35) x 32




M (M6x50) x 16




N (M6x55) x 4




O x 4




P




Q



ASSEMBLY OVERVIEW



Step 1




Do not over-tighten the bolts/screws




L x 2

Step 2

Pay attention to the position and direction of components , especially screw holes




B x 8




L x 8




Step 3






Step 4





Step 5



Step 6






Step 7





J x 2

Step 8




N x 2


Step 9




Step 10





Step 11





Step 12





Step 13





Step 14




Step 15




Step 16




Step 17



Step 18



ASSEMBLE ACCOMPLISHED



SAFETY AND MAINTENANCE

Every 6 months , check all screws to ensure they are tight .
Do Not use the product unless all screws are firmly secured .